

INSERTION OF THE TUBE INTO THE FITTING

- Make sure the tube is fully inserted into the fitting.
- To insert the tube into the fitting cut the tube at a squared angle (90°), insert up to the end and pull gently to make sure it is correctly connected.
- If there are any damages or scratches on the tube surface or an oval shape, air leakage and tube release may occur. Check it carrefuly.
- The OD of polyurethane tubes expand when pressure is applied. Reinsertion into the fitting may not be possible. Check the OD of the tube and change the tube if the expansion is serious.
- Always remove by cutting the part of the tube previously inserted into the fitting. Use a proper tube cutter in order to cut the tube.


DISCONNECTION OF THE TUBE FROM THE FITTING

- Make sure the pressure is zero before releasing the tube from the fitting.

- To release the tube, press the release ring regularly at the end and pull the tube with one hand.

Body

CONSTRUCTION MATERIALS



Back Ring

INSERTION TUBE

DIAMETER TUBES Ø	Ø4 mm	Ø6mm	Ø8mm	Ø10 mm	Ø 12 mm
TUBES INSERTION LENGHT (mm)	14	15,5	17,5	19	21

TOLERANCE TUBE

TUBES Ø	Ø4 mm	Ø6mm	Ø8mm	Ø10 mm	Ø 12 mm
TOLERANCES (mm)	± 0,1	± 0,1	± 0,1	± 0,15	± 0,15